





Assembly Instructions: 2 sheets Pattern: 21 sheets Number of parts: 76

You will need: Scissors, glue, ruler, a used ball-point pen

Assembly tip: Trace along the folds with a ruler and a used pen (no ink) to get a sharper,

easier fold.

----- Mountain fold ----- Valley fold — Scissors line

Glue spot ≥ Cut out

How to Play: Guide the ball through the maze from start to finish, rolling it past all kinds of obstacles and traps along the way. Try changing the way you tilt the maze to roll the ball, gently shaking it, or other tricky techniques to get past the windmills, slopes, and other obstacles.

You can have even more fun by trying out other types of balls and seeing how they roll differently. Try using a bead or small pebble to provide the weight for the ball included, or instead of the paper ball, use a round object about 12.5 mm (1/2") in size, like a bead or marble.







Caution: Glue, scissors and other tools may be dangerous to young children so be sure to keep them out of the reach of young children.































































































































